


FIG. 1



0015444 09160 11429160

FIG. 2





FIG.3

154

DATA RECONSTRUCTING TABLE			
1	SPARE STORAGE UNIT SPARE 1		SPARE STORAGE UNIT SPARE 2
2	STORAGE UNIT AT FAILURE #2		STORAGE UNIT AT FAILURE #4
3	POINT OF FAILURE		POINT OF FAILURE
4	FAILURE SECTOR OR ADDRESS	RECONSTRUC- TION JUDGEMENT FLAG	FAILURE SECTOR OR ADDRESS
	0000	1	0000
	0001	1	0001
	0010	1	0010
	⋮		⋮
	FFFF	0	FFFF
			5

FIG.4



09162444-092996

09162444-092998 866260-4429160

FIG.5




FIG.6




FIG.7




FIG.8




FIG. 9

